

Sabre LED Tube Battens

Installation & Maintenance Instruction Leaflet



Designed in Australia to comply with the requirements of CISPR15: 2011

Victoria (Head Office & Manufacturing)

195 Chesterville Rd
Moorabbin VIC 3189
Phone: +61 3 9559 2700
Fax: +61 3 9559 2799

New South Wales

Phone: +61 2 8805 6400
Fax: +61 2 8805 6444

Queensland

Phone: +61 7 3442 9700
Fax: +61 7 3442 9777

South Australia/Northern Territory

Phone: +61 8 8301 8800
Fax: +61 8 8351 8286

Western Australia

Phone: +61 8 9248 3720
Fax: +61 8 9248 3725

New Zealand

Phone: +64 800 548 448

Product Codes: FBS&L&-yy-zz

Lamp(s)	1 x 600mm LED Tube	840 G13, 825lm	&L& = 1L2	Diffuser	WireGuard	yy= WG
	2 x 600mm LED Tube	840 G13, 1650lm	&L& = 2L2		Prismatic	yy=DIF
	1 x 1200mm LED Tube	840 G13, 1650lm	&L& = 1L4	Option	Microwave Sensor	zz=MS
	2 x 1200mm LED Tube	840 G13, 3300lm	&L& = 2L4			

Important:

It is illegal for anyone, except for a licensed electrician to install or maintain this product. Before installation, ensure that the electricity supply has been switched off and isolated. Installation must be carried out in accordance with the relevant Australian and International Standards.

The LED Lamp tubes must only be replaced with another LED tube.

Installation:

This Sabre LED batten can be wall or ceiling mounted.

- Refer Images and Dimensions below for the mounting hole, cable access and other dimensions.
- Remove the wire guard or diffuser
- Remove the cover plate
- Position the batten in the desired location.
- Mark out the fixing points on the mounting surface.
- Install appropriate fixing hardware.
- Route power supply cables through the access hole as the rear of the fitting or the ends if using surface conduit (punch out the knock-outs in the plastic end caps)
- Fasten the batten to the surface.
- Terminate the supply cable to the terminals marked L, N and E (240V AC/50Hz)
- Re-attach the cover plate
- Re-install the diffuser or wire guard (if using a wire guard be sure to fix the wire guard into position using the screws provided that go through the side of the cover plate and over a section of the wire guard).

Warranty:

The manufacturer warrants the goods against defects solely due to faulty parts or workmanship of the manufacturer for a period of 24 months from the date of purchase. This warranty covers the repair or replacement of the goods at the discretion of the manufacturer, upon the goods being returned to the nearest branch of the manufacturer at the clients cost. Any other warranty or guarantee, expressed or implied, to the extent permitted by law, is expressly excluded. The manufacturer shall not be liable for any costs or consequential losses that may arise through the use of any of the manufacturers' products. Installation or operation of this product in a manner NOT complying with this instruction leaflet will automatically void any and all warranties.

Images and Dimensions:

