THIS PAGE INTENTIONALLY BLANK



240V 4ft LED Weatherproof Vandal Resistant Batten Installation & Maintenance Instruction Leaflet



Designed in Australia to comply with the requirements of AS/NZS CISPR15: 2011

Victoria (Head Office & Manufacturing)

Website: www.clevertronics.com.au Email: info@clevertronics.com.au Phone: +61 3 9559 2700 Fax: +61 3 9559 2799

New South Wales

Phone: +61 2 8805 6400 **Fax:** +61 2 8805 6444

Queensland

Phone: +61 7 3442 9700 **Fax:** +61 7 3442 9777

South Australia/Northern Territory

Phone: +61 8 8301 8800 Fax: +61 8 8351 8286

Western Australia

Phone: +61 8 9207 0000 Fax: +61 8 9207 0088

New Zealand

Phone: +64 800 548 448

Models: FVP4LED-P-xx-yy-uu-zz 240V 50Hz Options:

Options

Fused Terminal Block yy = FTB DALI LED Driver xx = DD Microwave Sensor Controlled Hi/Lo Function xx = MS-HL

Low Smoke Zero Halogen 1.5 metre Flex Cable with Wieland Plug Customized cable and plug configuration

7W Inline Filter

zz = LSZH-FPW1M5

zz = Custom uu = FLT

Spare Parts:

1330055 Replacement 240V Driver 1330056 Replacement 240V Driver (-DD) 1330070 Replacement 240V Driver (-MS-HL) 8002699 Replacement Emergency LED Board

Important:

It is illegal for anyone, except for a licensed electrician to install or maintain this product. Before installation, ensure that the electricity supply has been switched off and isolated. Installation must be carried out in accordance with the relevant Australian and International Standards.

17 June 2022

Installation:

The Vandal Resistant Batten is a surface mount fitting.

The batten can be attached directly to any solid surface by drilling the base internal mounts as required. Refer to the Dimensions Section for mounting points.

The batten can also be mounted to Unistrut utilizing the four (4) recessed screw holes on the back of the case. Refer to Dimensions section.


- 1. Remove the diffuser and gear tray. Position the batten base in the desired location.
- 2. Mark out the fixing points on the mounting surface.
- **3.** Fasten the batten to the surface, using appropriate fixing method.
- 4. Route power cable through the access hole. Use the conduit entry point at the end or drill a suitable entry hole in the rear of the batten body (must be suitably sealed after cable entry).
- Attach gear tray to lanyards.
- **6.** Wire mains power cable, 240V 50Hz, to terminals marked A, N &.
- 7. Fit gear tray and diffuser.

Sealing:

When drilling through the fitting base, a suitable silicone sealant must be applied to maintain the IP rating. Always use a sealant that remains flexible. Apply enough sealant so that the material oozes out completely around the washer when the bolt or screw is tightened.

Always use a gland or screwed conduit adapter. With conduit ensure that the other end of the conduit is not left open. Even if it is inside the building, it allows water vapor and insects to enter the fitting. A rubber washer and silicone sealant must also be used between the fitting body and the conduit nut inside the fitting to guarantee a water-tight seal. Use PVC cement to seal all conduit joints. Glands are intended for round cable and will not seal against TPS. Even when properly installed using round cable, sealant may be necessary in extreme weather exposure.

Dimensions:



Warranty:

For Product Warranty information and Terms and Conditions of Sales please refer to our website http://clevertronics.com.au/terms-conditions-sale-australia-nz/

1948708 V1.8 17 June 2022